


▲ Vorderkante Seitenwand
front edge of side wall

290



64

B





▼ cabinet floor bottom
Schrankboden unten



5



6



7




▼ Doorstrike bottom
Türanschlag unten

C

(140*)

135




04 / 2009 / 065




VAUTH-SAGEL

ÖKO-CENTER 1 + 2


Montageanleitung / Assembly instructions



ÖKO-CENTER 1




ÖKO-CENTER 2



44007307_00



▲ front edge of cabinet floor
Vorderkante Schrankboden

A




▼ Vorderkante
of side wall


front edge of side wall
Vorderkante Seitenwand



front edge of cabinet floor
Vorderkante Schrankboden



front edge of side wall
Vorderkante Seitenwand



cabinet floor bottom
Schrankboden unten

Doorstrike bottom
Türanschlag unten